

MULTI SCOOTER



SCAN FOR INSTRUCTION VIDEO



Always check whether the scooter is in a safe riding state before riding. Make sure that the handles and the screws on the wheels are securely locked. Adjust the handle to a comfortable height

Safety Tips. Check all the fastening objects before riding the loose parts to ensure that all the main body screws and pedals are in a fastened and safe state. There should be no abnormal sound, such as a clicking sound made by loose parts. Please consult relevant experienced professionals. Please wear protective equipment for safety equipment, such as safety-certified helmets, elbow pads, wrist guards, and knee pads. Always wear shoes when riding. Please do not wear bare feet or sandals. And please fasten the shoelace to make sure it stays away from the wheels

Warranty The scooter warranty period is 12 months, and the warranty scope is product parts and workmanship defects. If damage is caused by incorrect use, non-product quality problems are not covered by the warranty. This warranty does not cover normal wear and tear. Our company will not guarantee the damage caused by improper assembly, maintenance, storage and use. The following conditions are not warranted: a. Inappropriate use for entertainment or transportation purposes. b. In any way, if it is modified or leased to others, this warranty period is invalid. Please note this warranty in no way excludes your rights available under Australian Fair Trade Practices Act. Please refer to local regulations when using this product The manufacturer assumes no legal responsibility for direct or indirect losses and risks arising from the use of this product. If the product is damaged due to accident or long-term use, the manufacturer shall not be liable. If you want to obtain the warranty during the warranty period, please contact your local distributor or online distributor directly. Specifications are subject to change without notice. The manual contains important information, please keep it for future use.

Safety Tips-Before you let your child use our scooter, please make sure that the steering rod has been fully engaged and all screws have been tightened. At the same time, please make sure that the wheels have been tightened correctly and show no signs of wear. Before use, it must be assembled or checked by an adult. • Protective equipment should be worn. Make sure your child always wears a helmet. Expand- ed wrists, elbows, knee pads and shoes with rubber soles. *Make sure that your child does not slide down any steep slopes. The brake pads are not designed to slow down at high downhill speeds. The brake pads will become hot during use. In particular, make sure that your child does not leave the brakes on for a long time. Explain to your child that direct skin contact with the brake device may cause burns. Scooters cannot be used on traffic roads. This scooter can only be used by one child. • Your child should first practice the control of the vehicle, make sure that your child does not use it to try any experiments or adventures. • Loosening the axle screws multiple times will reduce the effectiveness of the screws to fasten the product, which means that the screws may loosen by themselves. Therefore, you should check and tighten it on a regular basis before use. For cleaning and maintenance, please wipe off the dust and dirt with a damp cloth. Do not use industrial cleaners, otherwise the surface of the product will be damaged. Do not use alcohol, or cleaners containing alcohol or ammonia, otherwise it will have a certain corrosive effect on the plastic parts of the product, or soften stickers or other appendages. Please store the scooter in a dry and dust-free place. Maintenance To protect your child from accidental injury, please regularly check whether all screws are tight and whether the wheels are in good condition. If they are worn out, please replace them. Please use a clean damp cloth to clean the scooter after each use. Under normal conditions of use of wheels and bearings, you are responsible for regular inspection and maintenance of the parts and bearings of the wheels. If the wheels make abnormal noise, please pay attention to replace the wheels and bearings at this time. Wheels and bearings are not covered by the warranty if they are damaged due to long-term use

Warning: Thank you for choosing our new scooter, we can guarantee that you have a high-quality product. We also provide you with quality after-sales service. Before you are sure that you have mastered the unique experience of operating the new scooter product, please read the instructions attached to the product carefully. It contains important safety, performance and maintenance knowledge. Please keep the manual for future reference.

Warning Only use scooters with fully engaged steering rods. Like riding a bicycle, skateboarding and roller skates. Even riding a scooter under good conditions is not necessarily completely safe and may cause accidents. Always make sure that your child wears a safety-approved helmet before riding a scooter. Failure to take safety precautions when falling from a scooter can cause serious or even fatal accidents. There is a risk of slipping in wet conditions. Do not use in these environments. Riding at dusk, at night or in low visibility conditions is very dangerous and increases the risk of accidental injury. Make sure your child always wears safety equipment in addition to the recommended safety equipment. Your child should wear bright, reflective clothing. The brake pads will become hot during use. Due to the small parts, there may be a risk of accidental swallowing by children. Not suitable for children under 3. Not suitable for children or teenagers weighing more than 50 kg. This scooter should be used with caution to avoid injury to the user and third parties caused by a fall or collision. Please do not use bicycles, motor-cycles, cars, etc. to tow. After a period of use, some metal parts may corrode. Especially if it is often used in humid environments such as the seaside or outside production. After use please do not store in direct sunlight and rain

Warning: You must wear protective equipment and use under adult supervision



①

INSTALL THE BARS

②

INSTALL THE SEAT BRACKET AND SELECT THE REQUIRED SEAT MOUNTING POSITION

③

HEIGHT SELECTION
A
B
C

SELECT THE SEAT HEIGHT AND FIX IN POSITION

④

INSTALL THE BACKREST

⑥

MOUNT THE PUSH BAR TO SCOOTER DECK AND CONNECT THE BACK REST TO THE SEAT

⑦

INSTALL THE BUG!